

# LED Tri-proof Batten Light with Sensor | 24W







Motion+daylight sensor Detection area: 4-6 m

Hold on time: 30s/1min/10min/30min

With remote control

## Shenzhen ERS Technology

Factory Add: C209,Baohuasen International Center, Qianjin Second Road,Xixiang Town,Bao'an District,Shenzhen,China Warehouse Add: 25 Meriton Place, Clayton South, VIC 3169

**Tel:** 0401 826 618

















#### **APPLICATION**

Indoor and outdoor lighting, with IP65, it can be used at chick en farm, basement, car pariking, warehouses, corridors, outside of building, etc



#### **SPECIFICATIONS**

Item Code	ERS-TRI24WS		
Product Size (mm)	1207X91X78		
Power	24W		
Sensor	Daylight&Microwave Motion Sensor,Sensing distance 4–6M		
Input Voltage	AC220~240V,50Hz		
Opal Diffuser Material	PC		
Body Mateial	PC		
Body Colour	Grey		
Clips	stainless steel clips		
Driver Brand	PHILIPS Element non—isolated driver 3 years warranty		
Efficiency	150lm/w		
LED Type	SMD 2835		
ССТ	3000K,4000K,5000K,6500K		
CRI	Ra > 80		
Power Factor	> 0.9		
Beam Angle	120°		
IP Rating	IP65		
Warranty	3 years		
VEET	Approved		
IPART	Approved		

# Shenzhen ERS Technology

Factory Add: C209,Baohuasen International Center, Qianjin Second Road,Xixiang Town,Bao'an District,Shenzhen,China Warehouse Add: 25 Meriton Place, Clayton South, VIC 3169

**Tel**: 0401 826 618


















#### LED MANUNAL INSTRTION



- 1 Installation should be done by registered electricians.
- 2 Before replacing the driver, please switch off the power supply and wait until it cools down completely.
- 3 Never touch the working luminaire
- 4 In any case of malfunction, switch off the power supply immediately, and do not try to repair it yourself.
- **5** Repairment should only be done by registered electricians or official service agent.





Model	Power	Fixing Hole Centre
ERS-TRI12WS	12W	280mm
ERS-TRI24WS	24W	770mm
ERS-TRI36WS	36W	770mm






Switch off the power supply before installation









bolts and screws, instal the bracket.








1. Unbuckle the clips




2. Take out of the diffuser






4. Take out of the LED module



5.Insert the cable through the cable gland



6.Connect the wires,L to L, N to N, ⊕ to ⊕

### Shenzhen ERS Technology

Factory Add: C209, Baohuasen International Center, Qianjin Second Road,Xixiang Town,Bao'an District,Shenzhen,China Warehouse Add: 25 Meriton Place, Clayton South, VIC 3169

Tel: 0401 826 618



























7. Put back the LED module


8. Close the luminaire

9. Buckle the clips










# **PACKING**

N.W.(KG)	G.W.(KG)	CARTON SIZE(mm)	QTN/CTN
12.6	14.6	1225X290X260	9



#### Shenzhen ERS Technology Factory Add: C209,Baohuasen International Center, Qianjin Second

Road, Xixiang Town, Bao'an District, Shenzhen, China Warehouse Add: 25 Meriton Place, Clayton South, VIC 3169

**Tel:** 0401 826 618


















#### **DETAILS**







# Shenzhen ERS Technology

Factory Add: C209,Baohuasen International Center, Qianjin Second Road,Xixiang Town,Bao'an District,Shenzhen,China Warehouse Add: 25 Meriton Place, Clayton South, VIC 3169

Tel: 0401 826 618













